Let's Get Started! Setting Up Cobalt TV using Coax Cable

Connect the Modem

The contents of this bag will replace your existing DSL Modem.

- 1. Power up the Modem by connecting it to a wall outlet using the included power adapter.
- 2. Connect the telephone cord from the DSL/telephone jack in the wall to the DSL port in the Modem.
- 3. Power up the MOCA box by connecting it to a wall outlet using the included power adapter.
- 4. Connect the Ethernet Cord from LAN port 3 or 4 to the Ethernet port in the MOCA box.
- 5. Connect the Coax Cable from the coax port in the MOCA box to the coax port in the wall.
- 6. You have completed the set up for this room! Now take the appropriate white room bag to the first room you would like to set up.



