


# Controlling the Remote



## WHAT'S ON TV?

There's more than one way to see what's showing on TV.



### Info Button

Press **INFO** and you will see the name and a description of the current program at the top of the screen.



### OK Button

Press **OK** to show the **Now Playing** bar and you will see what program is currently playing.



### Guide Button

This is the most comprehensive view of what's on. Go ahead and page through . . . you're bound to find something you want to watch.



### Right Arrow Browse Button

Press the **Right Arrow** to view the channel you are currently watching. At the bottom of the screen, the **Info Bar** shows you the channel number, channel name, time the program airs, a progress bar, and the program that airs next.

\*Available with DVR

## Remote Control Set Up

Make sure TV is ON before starting the remote control setup.

- 1 Press and hold **SETUP** until it blinks twice.




- 2 Press the **TV POWER** key.



- 3 Press and hold down the **OK/SELECT** key.



- 4 When the TV turns off, let go of the **OK/SELECT** key.



- LOW BATTERY**
- The **CABLE POWER** button will blink 5 times with each key-press when the batteries need replacement.



1006 12th Street • Aurora, NE 68818 • 402.694.5101

[CobaltTV.com](http://CobaltTV.com)

## Remote Control Guide

